
MEW4-1


Quick Start









Aircraft



^{*}Please turn to User Manual for detailed information of flight environment requirements.

Remote Controller





- 1. Power switch
- 2. One-key RTH
- 3. Left stick
- 4. Right stick
- 5. Photo/Video
- 6. One-key unlock/lock
- 7. Mobile phone holder
- 8. Antenna
- 9. Hand stick
- 10. LCD display
- 11. One-key takeoff/One-key landing
- Light switch (short-press);
 High/Low speed switch (long-press)
- 13. Gimbal trimmer
- 14. GPS/Gesture mode switch

- Photo/Video
 Short-press to take photos;
 Long-press to take videos.
- One-key takeoff/ One-key landing Short-press to switch one-key takeoff or one-key landing.
- One-key unlock/lock Short-press to unlock; Long-press to lock.
- Light switch (short-press);
 High/Low speed switch
 (long-press)
 Short press to turn on/off the LED lights;
 Long-press to switch High/Low speed.

One-key RTH


Short-press to enter into RTH procedure; Press again to exit RTH.


GPS/Gesture mode switch

OFF - Gesture Mode;

ON - GPS Mode.


Gimbal trimmer





The camera can be rotated by 180 degrees.

LCD screen display



Return to Home (RTH) icon

The icon is on during the RTH procedure and will be off once RTH procedure canceled.

Aircraft battery level

It indicates current aircraft battery level.

It indicates current aircraft flying distance against recorded Home Point.

Satellite amount
Once the GPS signal amount is over 7, Home Point will
be recorded at the location where the aircraft takes off.

High/Low speed mode LOW - Low Speed; HIGH - High Speed.

Signal strength

It indicates the signal strength that the remote controller receives from the aircraft.

Photo/Video

Flashing once to take photos; Keep flashing to take videos.

Remote controller battery level

It indicates remote controller current battery level.

H3 I5 Altitude against Home Point

It indicates aircraft current altitude against Home Point.

mode Remote controller throttle mode


It indicates current throttle mode. Throttle mode is set at Mode 2 by default.

GPS mode


ON - GPS Mode; OFF - Gesture Mode.

Preparation before Use Downloa

Prepare your MEW4-1



Flight Preparation




Signal connection






Keep pressing the unlock button and turn on the remote controller.





Power on the aircraft by pressing the switch on the aircraft for 3 seconds.

Compass calibration



Step 1. Rotate the MEW4-1 360 degrees for 3 circles horizontally.





Step 2. Rotate the MEW4-1 360 degrees for 3 circles vertically.

Flight

Unlock the aircraft




Short-press the unlock button.

Change the throttle mode











Keep pressing the RTH button for 3 seconds to change the throttle mode.

Control the aircraft


Throttle mode is set at Mode 2 by default. Left stick determines the aircraft's altitude and orientation; Right stick controls the stick's movement.

Mode 1 is opposite to Mode 2. That's to say, in Mode 1, right stick determines the aircraft's altitude and orientation; Left stick controls the stick's movement.


















Turn off the remote controller and aircraft



Long-press the unlock button and turn off the remote controller.

Power off your aircraft by pressing the switch for 3 seconds.

Charge the Aircraft Battery

- The aircraft's battery needs to be full charged before every flight;
- Please use the original default charging device for this aircraft;
- Full Charging time takes about 180 minutes.

